



- ① Choose desired height 1, 2 or 3.
- ② Insert wire stand prongs into holes of legs.
NOTE: Squeeze prongs to fit into holes.
- ③ To angle the wire stand, choose a different height for the opposite leg.
- ④ **NOTE:** Larger pedestal legs have 4 heights to choose from.

